PARTS LIST FOR RVLII15LW and RVLII20LW

REEL ASM. Nos 1639168(15LW) and 1639138(20LW)



KEY NO.	PART NO.	PENN STYLE NO.	DESCRIPTION
1	1646244	1-RVLII15LW	Right Side Plate
1	1646245	1-RVLII20LW	Right Side Plate
2	1646246	2-RVLII15LW	Right Side Ring
3	1384179	3-WAR15LW	Bridge
4	1382976	4-WAR15LW	Drag Washer
5	1382977	5-WAR15LW	Main Gear
6	1382978	6-WAR15LW	Tabbed Drag Washer(2 req)
7	1382999	7-WAR15LW	Keyed Metal Drag Washer
7H	1383000	7H-WAR15LW	Heavy Metal Drag Washer
8	1383001	8-WAR15LW	Spring Washer(4 req)
9	1384180	9-WAR15LW	Spacing Sleeve
10	1646247	10-RVLII15LW	Star Drag
10B	1383004	10B-WAR15LW	Star Click Washer(2 req)
11	1645952	11-WARII15LW	Eccentric Jack
12	1383007	12-WAR15LW	Pinion Yoke
13	1645953	13-WARII15LW	Pinion
15	1383009	15-WAR15LW	Anti Reverse Dog
15A	1646248	15A-RVLII15LW	Click Spring
15B	1646249	15B-RVLII15LW	Anti Reverse Dog
16	1383010	16-WAR15LW	Screw(2 req)
18	1383011	18-WAR15LW	Pinion Yoke Spring(2 req)
19	1383012	19-WAR15LW	Eccentric
20	1383013	20-WAR15LW	Eccentric Spring
21	1646250	21-RVLII15LW	Eccentric Lever
22	1383015	22-WAR15LW	Eccentric Screw
23	1383016	23-WAR15LW	Handle Assembly Screw
23A	1645955	23A-WARII15LW	Handle Lock Screw
23B	1383018	23B-WAR15LW	Handle Screw Washer
24	1646251	24-RVLII15LW	Handle Assembly
24A	1383020	24A-WAR15LW	Handle Thrust Washer
26	1383021	26-WAR15LW	Spool Tension Control Cap
26A	1383022	26A-WAR15LW	Bushing(2 req)
26B	1383023	26B-WAR15LW	Clutch Retainer
26C	1383024	26C-WAR15LW	Screw(2 req)
27	1646252	27-RVLII15LW	Left Side Plate
27	1646253	27-RVLII20LW	Left Side Plate
28	1646254	28-RVLII15LW	Left Side Ring
29	1646255	29-RVLII15LW	Spool
29	1646256	29-RVLII20LW	Spool
29A	1451532	29A-WAR15LW	Pin
29L	1646257	29L-RVLII15LW	Spool Assembly
29L	1646258	29L-RVLII20LW	Spool Assembly
33	1182754	33-113	Rod Clamp
34	1182788	34-045	Screw (2 req)
35	1645964	35-WARII15LW	Click Tongue
36	1645965	36-WARII15LW	Click Button
38	1645966	38-WARII15LW	Screw (7 req)

KEY NO.	PART NO.	PENN STYLE NO.	DESCRIPTION
39A	1383041	39A-WAR15LW	Screw (2 req)
40	1383042	40-WAR15LW	Ball Bearing
40A	1645967	40A-WARII15LW	Ball Bearing Retainer
40B	1645968	40B-WARII15LW	Felt Washer
40C	1383045	40C-WAR15LW	Washer, Acetal Thrust
40D	1383046	40D-WAR15LW	Washer, Rubber Thrust
40E	1383047	40E-WAR15LW	Thrust Washer (2 reg)
41A	1384181	41A-WAR15LW	Bushing
42	1645969	42-WARII15LW	Worm Shaft Assembly
42	1645970	42-WARII20LW	Worm Shaft Assembly
43	1383051	43-WAR15LW	Worm Shaft Bushing(2req)
46	1645971	46-WARII15LW	Line Guide Assembly
47	1383053	47-WAR15LW	Line Guide Pawl
47A	1383054	47A-WAR15LW	Pawl Shim
48	1383055	48-WAR15LW	Line Guide Nut
50	1383056	50-WAR15LW	Worm Shield
50	1383057	50-WAR20LW	Worm Shield
55	1451533	55-WAR15LW	Ball Bearing
58	1645972	58-WARII15LW	Line Guide Post
58	1645973	58-WARII20LW	Line Guide Post
58A	1645974	58A-WARII15LW	Line Guide Guard Post
58A	1645975	58A-WARII20LW	Line Guide Guard Post
60A	1645976	60A-WARII15LW	Worm Shaft Washer
60	1383060	60-WAR15LW	Worm Shaft Washer
62	1645977	62-WARII15LW	Click Spring
62A	1645978	62A-WARII15LW	Click Spring Guard
62B	1645979	62B-WARII15LW	Screw
62C	1645980	62C-WARII15LW	Screw(2 req)
64	1645981	64-WARII15LW	Idler Gear
64A	1645982	64A-WARII15LW	Idler Gear
66	1645983	66-WARII15LW	Click Ratchet
69	1633161	69-WARII15LW	Retainer Ring
69A	1633187	69A-WARII15LW	Retainer Ring
69C	1645984	69C-WARII15LW	Retainer "C" Ring
98	1383067	98-WAR15LW	Main Gear Shaft
98R	1383069	98R-WAR15LW	Anti Reverse Ratchet
98S	1383070	98S-WAR15LW	Clutch Sleeve
120	1383071	120-WAR15LW	O-Ring
134A	1383072	134A-WAR15LW	Clutch Recover Plate
134B	1383073	134B-WAR15LW	Clutch Recover Support Plate
134C	1383074	134C-WAR15LW	Clutch Recover Spring
149	1184702	149-045	Rod Clamp Nut (2 req)
149A	1184706	149-200	Hex Nut (2 req)
154	1383077	154-WAR15LW	Click Button Washer
158	1383078	158-WAR15LW	Dog Pin(2req)
183	1646259	183-RVLII15LW	Frame Assembly
183	1646260	183-RVLII20LW	Frame Assembly