
www.reelschematic.com

QUANTUM®

BRT20NW



Quantum Blue Runner BRT20NW Trolling Reel Part List

Key #	Description	Part No. BRT20NW	Key #	Description	Part No. BRT20NW
1	Side Cover Screw -A (Palm)	JI125-01	35	Trip Ratchet Spring	EI097-01
2	Side Cover Screw -B (Palm)	JI123-01	36	Trip Ratchet	EI083-01
3	Palm Side Cover Metal Ring	KI133-01	37	Crank Shaft	EI008-01
4	Bait Click Lever	EI109-01	38	Anti Reverse Ratchet	FI083-01
5	Palm Side Cover	KI023-01	39	Ratchet Washer	EI111-01
6	Bait Click Pawl	EI114-01	40	Drive Gear	EI012-01
7	E-Clip	NX092-01	41	Drag Disc "A"	EI059-01
8	Bait Click Spring	EI110-01	42	Drag "D" Washer - A	EI045-01
9	Bait Click Spring Screw	WW107-01	43	Drag Disc "B"	FI059-01
10	Spool Shaft Washer	EI035-01	44	Drag Key Washer	EI048-01
11	Spool Shaft Bearing - Palm	KI017-01	45	Drag "D" Washer - B	FI045-01
12	Oscillate Drive Gear	EI112-01	46	Spring "D" Washer	EI046-01
13	Oscillate Drive Gear Screw	EI057-01	47	Crank Shaft Washer	EI038-01
14	Spool Assembly	EI321-01	48	Crank Shaft Bushing - Outer	EI066-01
15	Spool Cover	EI051-02	49	Crank Shaft Bushing - Inner	FI117-01
16	Line Guide Post	KI061-01	50	Star Drag Washer	FI032-01
17	Frame Post	FI061-01	51	Release Slider Cam	EI141-01
18	Reel Foot	EI106-01	52	Release Slider Cam Spring	EI104-01
19	Reel Foot Screw	EI107-01	53	Gear Side Cover	JI024-02
20	Worm Shaft Bushing	EI067-01	54	Gear Side Cover Metal Ring	JI133-01
21	Spacer Bar	KI094-01	55	Clutch Lever	JI142-01
22	Spool Shaft Bearing - Gear	GI017-01	56	Clutch Lever Screw	EI053-01
23	Set Plate	EI010-02	57	Tension Knob Spring	EI105-01
24	Release Slider	EI039-01	58	Spool Tension Washer	EI032-01
25	Pinion Gear	EI011-01	59	Spool Cushion Washer	EI082-01
26	Pinion Yoke	EI025-01	60	Spool Tension Knob	GI033-01
27	Pinion Yoke Spring	EI040-01	61	Star Drag	EI055-01
28	Anti Reverse Pawl Post	EI098-01	62	Handle Washer	EI054-01
29	Anti Reverse Pawl	EI063-01	63	Handle Assembly	EI318-02
30	Anti Reverse Pawl Spring	EI096-01	64	Handle Nut	EI003-01
31	E-Clip	QW120-01	65	Handle Nut Retainer	EI034-01
32	Crank Shaft Bushing Washer	FI035-01	66	Handle Nut Retainer Screw	FI123-01
33	Crank Shaft Bushing	EI117-01	67		
34	Trip Ratchet Spring Holder	EI103-01	68		