QUANTUM

BR80F



Quantum BLUE RUNNER BR80F Part List

Key #	Description	BR80F	Key #	Description	BR80F
1	DRAG KNOB ASSEMBLY	N/A	22	SCREW - LINE SLIDER	AQ108-01
2	SPOOL RETAINER - TOP	BT038-02	23	SCREW - ARM LEVER	GS044-01
3	DRAG WASHER "D"	JS080-01	24	PIN	GS031-01
4	DRAG WASHER "B"	BT033-01	25	SPRING	GS022-01
5	DRAG WASHER "A"	BT081-01	26	PIN HOLDER	GS020-01
6	DRAG WASHER "D"	BT080-01	27	ARM LEVER COVER	JS087-01
7	SPOOL BEARING KIT	BT4160-01	28	A/L SIDE COSMETIC COVER	GS135-01
	7A - SPOOL BUSHING	QTY - 2	29	ROTOR	JS009-01
	7B - SPOOL SPACER	QTY - 1	30	MAIN SHAFT KIT	JS4015-01
8	SPOOL ASSEMBLY KIT	KS4321-01		30A - MAIN SHAFT	QTY - 1
	8A - SPOOL ASSEMBLY	QTY - 1		30B - MAIN SHAFT PIN	QTY - 1
	2 - SPOOL RETAINER - TOP	QTY - 1	31	SCREW A/R STOPPER	
	3 - DRAG WASHER "D"	QTY - 1	32	A. R. STOPPER	GS063-01
	4 - DRAG WASHER "B"	QTY - 3	33	A. R. CLAW SPRING	GS061-01
	5 - DRAG WASHER "A"	QTY - 2	34	RATCHET GEAR	JS060-01
	6 - DRAG WASHER "D"	QTY - 1	35	SLIDE SPRING	JS086-01
	7 - SPOOL BUSHING/BEARING KIT	QTY - 1	36	SCREW, BEARING RETAINER	
	8B - SPOOL WASHER	QTY - 1	37	PINION/BODY BALL BEARING	BT157-01
	8C - DRAG CLICK ASSEMBLY	QTY - 1	38	GEAR KIT	GS4011-01
	8D - DRAG WASHER "E"	QTY - 1		38A - PINION GEAR	QTY - 1
	9 - SPOOL RETAINER - BOTTOM	QTY - 1		38B - DRIVE GER	QTY - 1
9	SPOOL RETAINER - BOTTOM	BT038-01		38C GEAR ADJUST. WASHER	QTY - 1
10	ROTOR NUT LOCK SCREW	JS094-01	39	HANDLE SCREW CAP KIT	GS4073-01
11	ROTOR NUT	BT006-01		39A - HANDLE CAP SCREW	QTY - 1
12	E-CLIP - BAIL ASSEMBLY	GH034-01		39B - H/CAP SCREW WASHER	QTY - 1
13	A/L/BAIL HOLDER COVER SCREW	GU077-02A	40	BODY ASSEMBLY	JS301-02
14	BAIL HOLDER COVER	JS024-01	41	O/S GEAR BUSHING OR BEARING	BT158-01
15	KICK LEVER	JS019-01	42	O/S GEAR	GS053-01
16	BAIL ASSEMBLY	JS347-01	43	O/S SLIDER	GS025-01
17	LINE ROLLER WASHER	JS102-01	44	MAIN SHAFT SCREW	RQ100-01
18	LINE ROLLER BUSHING	JS202-01	45	BODY COVER	JS023-02
19	LINE ROLLER	CH004-02	46	BODY COVER SCREW	AT057-01
20	LINE ROLLER COLLAR	CH102-01	47	HANDLE ASSY	GS318-01
21	ARM LEVER ASSY.	JS307-01			