


ReelSchematic

SMOKE X BAITCAST LH

QUANTUM®

Quantum SMOKE X SMX101SPT Part List

Key No.	Description	Part No.	Q'ty	Key No.	Description	Part No.	Q'ty
1	Palm Side Cover Kit include	VB4323-03	1	37	Release Slider Link Screw	EW125-01	1
	1A - Palm Side Cover Assembly	VB323-03	1	38	Release Slider Screw	CX076-03	1
	1B - Centrifugal Dial	VB026-01	1	39	Pinion Yoke	TB025-01	1
	1C - Centrifugal Dial Friction Ring	SB105-01	1	40	Yoke Spring	GX040-01	2
	1D - Centrifugal Dial Click Spring	VB114-01	1	41	Pinion Gear	HB011-02	1
	1E - Centrifugal Dial Click Pawl	PW098-01	1	42	Crank Shaft Ball Bearing - L	SW017-06	1
	1F - Spool Cover	VB051-01	1	43	E-Clip	QW120-01	1
	1G - Space Washer	PW032-01	2	44	Crank Shaft Retainer	UB002-01	1
	1H - Spool Tension Shim	QW032-04	1	45	Crank Shaft Retainer Screw	JX107-02	2
	1J - Spool Shaft Ball Bearing - Palm	QV017-04	1	46	Crank Shaft	YW008-06	1
	1K - Clip Ring	HV080-01	1	47	O/S Drive Gear	UB112-01	1
	1L - Spool Cover Screw	ZW053-03	4	48	Trip Ratchet	PW083-02	1
	1M - Brake Ring Assembly	VB342-01	1	49	Trip Ratchet Washer	YW111-01	1
	1N - Brake Ring Slider Spring	UB040-01	3	50	Drive Gear	HB012-02	1
	1P - Brake Ring Slider Spring Retainer	UB129-01	1	51	Drag Key Washer	PW048-01	2
	1Q - Screw	DW107-03	3	52	Drag Disc - A	PW059-01	2
	1R - Tethered Spring	UB070-01	1	53	Drag "D" Washer	YW045-02	1
2	Spool Assembly	VB321-01	1	54	Drag Disc - B	YW059-01	1
3	Locking Lever Retainer Screw	KW107-01	2	55	Drag Washer	UB045-01	1
4	Locking Lever Retainer "A"	UB056-02	1	56	One Way Clutch Sleeve	UB052-01	1
5	Locking Lever Spring	UB114-01	1	57	Clip Ring	EB080-01	1
6	Locking Lever Retainer "B"	UB136-02	1	58	Tension Knob Ball Bearing	SW017-06	1
7	Thumb Bar Screw	CW125-01	2	59	Gear Side Cover Assembly	VB324-23	1
8	Thumb Bar Assembly	VB309-04	1	60	Gear Side Cover Screw "A"	UB053-01	2
9	Locking Lever	VB062-01	1	61	Gear Side Cover Screw "B"	UB053-02	1
10	Frame	VB001-21	1	62	Tension Knob Click Spring	PW114-01	1
11	E-Clip	NX092-01	1	63	Click Ratchet Retainer	YW080-01	1
12	Bearing Retainer	VB067-01	1	64	Tension Knob Click Ratchet	PW113-01	1
13	Worm Shaft Ball Bearing	XX117-04	1	65	Spool Tension Shim	QW032-04	1
14	Worm Shaft Guide	SB016-01	1	66	Space Washer	PW032-01	2
15	Worm Shaft	UB072-02	1	67	Spool Tension Cushion Washer	EX082-02	1
16	Line Guide Carrier Assembly	UB347-21	1	68	Spool Tension Knob	UB033-20	1
17	Line Guide Pawl	ZW006-01	1	69	Crank Shaft Bearing	TW058-09	1
18	Carrier Washer	BV035-01	1	70	Crank Shaft Washer	TW035-02	1
19	Line Guide Carrier Screw	ZW007-01	1	71	Drag Click Spring Assembly	YX4114-01	1
20	Front Support Screw	KW107-01	3	72	Spring "D" Washer	JX046-01	2
21	Front Support	VB099-20	1	73	Star Drag Washer	ZW032-01	1
22	Worm Shaft Bushing - Gear Side	PW068-01	1	74	Star Drag	VB055-04	1
23	O/S Pinion Gear Washer	EX035-01	1	75	Handle Washer	NX054-01	1
24	O/S Pinion Gear	UB085-01	1	76	Handle Assembly	UB318-21	1
25	Pin	UB093-01	1	76A	Handle Knob Bushing	BC158-01	2
26	Side Cover Screw	ZW053-05	1	76B	Handle Knob Assembly	UB313-01	2
27	Tethered Shaft Stop Screw	UB123-01	1	76C	Handle Knob Bearing	DT202-05	2
28	Kick Lever Plate	VB010-01	1	76D	Handle Knob Screw	QW123-01	2
29	Kick Lever Plate Screw	KW107-02	3	76E	Handle Knob Cap	BC115-20	2
30	Kick Lever Spring	TB097-01	1	77	Handle Nut	UB003-02	1
31	Kick Lever	YW077-01	1	78	Handle Nut Retainer	UB034-01	1
32	Kick Lever Guide Plate	SB161-01	1	79	Line Memo Click Spring	UB096-01	2
33	Kick Lever Guide Plate Screw	JX107-02	1	80	Line Memo Click Pawl	UB098-01	2
34	Release Slider Spring	TB104-01	1	81	Line Memo Dial	UB162-02	1
35	Release Slider	VB039-01	1	82	Line Memo Dial Cover	UB145-01	1
36	Release Slider Link	VB036-01	1	83	Handle Nut Cap Screw	DW050-02	1