QUANTUM®

SR60



ReelSchematic

Quantum SR60 Part List

Key No.	Description	Part No. SR60	Qty	Key No.	Description	Part No. SR60	Qty
1	Drag Knob Assembly	JAE332-01	1	31	Rotor Washer	KAE110-01	1
2	Spool Retainer	EAE038-01	1	32	Clutch Retainer Screw	EAE057-01	3
3	Drag Washer "D"	JAE080-01	2	33	Clutch Stack Retainer	EAE040-01	1
4	Drag Washer	JAE081-01	3	34	Top Pinion Ball bearing	TW058-01	1
5	Eared Washer	JAE033-01	1	35	Clutch Bearing Adapter	GAE019-01	1
6	Spool Assembly	KAE320-01	1	36	One Way Clutch Unit	GAE363-01	1
7	Spool Adjust Washer	JAE030-01	1	37	One Way Clutch Spring	EAE216-01	1
8	Clicker Gear	JAE037-01	1	38	Sleeve	JAE139-01	1
9	Spool Clicker Washer	JAE045-01	1	39	Pinion	JAE011-01	1
10	Main Shaft	JAE015-01	1	40	Stopper Cam	GAE090-01	1
11	Rotor Nut	JAE006-01	1	41	Stopper Lever	GAE059-01	1
12	Rotor Nut Lock Screw	EAE094-01	1	42	Stopper Cam Spring	EAE120-01	1
13	Rotor Fasten Shim	JAE110-01	1	43	Stopper Cam Screw	EAE135-01	1
14	Rotor	KAE009-01	1	44	Body Assembly	JAE301-01	1
15	Bail Holder Side Cover	KAE087-01	1	45	Handle Screw Cap	EAE073-01	1
16	Line Roller Screw	EAE108-01	1	46	Toothed lock washer	EAE075-01	1
17	Arm Lever	JAE007-01	1	47	Body ball bearing	TW058-01	1
18	Line Roller Collar	EAE102-01	1	48	Drive Gear	JAE012-01	1
19	Line Roller Washer	FAE102-01	1	49	Cover ball bearing	TW058-01	1
20	Ball Bearing	CT157-01	2	50	O/S Gear Bearing	NA	1
21	Line Roller	GAE004-01	1	51	O/S Gear	JAE053-01	1
22	Bail Assembly	KAE347-01	1	52	O/S Gear Screw	JAE057-01	1
23	Arm Lever Screw	EAE042-01	1	53	O/S Slider	JAE025-01	1
24	Bail Holder Screw	EAE042-01	1	54	Side Cover Assembly	JAE323-01	1
25	Kick Lever	KAE019-01	1	55	Side Cover Screw	NA	1
26	Actuator Lever	EAE116-01	1	56	Side Cover Screw	FAE085-01	4
27	Actuator Spring	EAE022-01	1	57	Handle Assembly	JAE418-01	1
28	Actuator	EAE031-01	1				
29	Arm Lever Side Cover	GAE087-01	1				
30	Arm Lever Side Cover Screw	EAE077-01	1				