


# THROTTLE BAITCASTING TH101HC

QUANTUM®

ReelSchematic

# Quantum Throttle TH101HC Part List

| Key No. | Description | Part No. TH101HC | Q'ty | Key No. | Description | Part No. TH101HC | Q'ty |
|---|---|---|---|---|---|---|---|
| 1 | Palm Side Cover Kit includes: | BC4023-11 | 1 | 27 | Kick Lever Spring | BC097-01 | 1 |
| | 1A - Palm Side Cosmetic Cover | BC133-11 | 1 | 28 | Kick Lever | BC077-01 | 1 |
| | 1B - Palm Side Cover | BC023-11 | 1 | 29 | Release Slider Screw | AC076-01 | 2 |
| | 1C - Cosmetic Cover Screw | BC053-01 | 2 | 30 | Pinion Yoke | BC025-01 | 1 |
| | 1D - Magnet Dial | AC026-03 | 1 | 31 | Yoke Spring | AC040-01 | 2 |
| | 1E - Magnet Dial Click Spring | AC108-01 | 1 | 32 | Pinion Gear | AC011-02 | 1 |
| | 1F - Magnet Dial Friction Ring | BC105-01 | 1 | 33 | Crank Shaft Bearing | SW017-06 | 1 |
| | 1G - Slide Cam "B" | BC028-01 | 2 | 34 | E-Clip | QW120-01 | 1 |
| | 1H - Slide Cam "A" | AC028-01 | 1 | 35 | Crank Shaft Retainer | AC002-01 | 1 |
| | 1J - Magnet Adjust Spring | BC022-01 | 2 | 36 | Crank Shaft Retainer Screw | AC050-01 | 1 |
| | 1K - Side Cover Locking Pin Spring | AC070-01 | 1 | 37 | Crank Shaft | AC008-02 | 1 |
| | 1L - Side Cover Locking Pin | BC103-01 | 1 | 38 | O/S Drive Gear | AC112-01 | 1 |
| | 1M - Spool Cover | BC051-01 | 1 | 39 | Trip Ratchet | AC083-01 | 1 |
| | 1N - Spool Cover Screw "A" | AC107-01 | 2 | 40 | Trip Ratchet Washer | AC111-01 | 1 |
| | 1P - Spool Cover Screw "B" | BC050-02 | 1 | 41 | Drive Gear | AC012-02 | 1 |
| | 1Q - Magnet Assembly | AC330-01 | 3 | 42 | Drag Disc | AC059-01 | 1 |
| | 1R - Slide Cam Screw | BC050-02 | 2 | 43 | Drag Washer | AC045-01 | 1 |
| | 1S - Spool Tension Shim | BC121-01 | 1 | 44 | One Way Clutch Sleeve | AC052-01 | 1 |
| | 1T - Palm Side Spool Shaft Ball Bearing | QV017-05 | 1 | 45 | One Way Bearing Screw | AC053-01 | 2 |
| | 1U - Clip Ring | AC080-01 | 1 | 46 | One Way Bearing | AC063-01 | 1 |
| 2 | Spool Assembly | AC321-03 | 1 | 47 | Spool Tension Knob Ball Bearing Retainer | AC080-01 | 1 |
| 3 | Locking Lever Retainer Screw | YB107-03 | 1 | 48 | Spool Tension Knob Ball Bearing | SW017-06 | 1 |
| 4 | Locking Lever Retainer | AC056-02 | 1 | 49 | Gear Side Cosmetic Cover Screw | BC053-01 | 2 |
| 5 | Locking Lever Spring | AC096-01 | 1 | 50 | Gear Side Cover Assembly | BC324-11 | 1 |
| 6 | Locking Lever | BC119-01 | 1 | 51 | Gear Side Cosmetic Cover | BC145-11 | 1 |
| 7 | Frame | BC001-11 | 1 | 52 | Gear Side Cover Screw "A" | AC057-01 | 2 |
| 8 | E-Clip | NX092-01 | 1 | 53 | Spool Tension Knob O-Ring | QW101-01 | 1 |
| 9 | Worm Shaft Bushing | BC067-01 | 1 | 54 | Spool Tension Washer | AC032-01 | 1 |
| 10 | Worm Shaft | AC072-01 | 1 | 55 | Spool Tension Support Washer | BC032-01 | 1 |
| 11 | Line Guide Carrier | AC047-01 | 1 | 56 | Spool Cushion Washer | AC082-01 | 1 |
| 12 | Front Support Screw | BC050-02 | 3 | 57 | Spool Tension Knob | AC033-02 | 1 |
| 13 | Front Support | BC099-11 | 1 | 58 | Crank Shaft Ball Bearing | TW058-09 | 1 |
| 14 | Line Guide Pawl | AC006-01 | 1 | 59 | Crank Shaft Washer | BC035-01 | 1 |
| 15 | Carrier Washer | AC035-01 | 1 | 60 | Drag Click Spring Assembly | AC4114-01 | 1 |
| 16 | Line Guide Carrier Screw | AC007-01 | 1 | 61 | Spring "D" Washer | AC046-01 | 2 |
| 17 | Stablizer Bar | AC061-01 | 1 | 62 | Star Drag Washer | AC038-01 | 1 |
| 18 | Worm Shaft Guide | AC016-01 | 1 | 63 | Star Drag | BC055-01 | 1 |
| 19 | O/S Pinion Gear | AC085-01 | 1 | 64 | Handle Washer | AC054-01 | 1 |
| 20 | O/S Pinion Gear Pin | AC093-01 | 1 | 65 | Handle Assembly | AC318-21 | 1 |
| 21 | Thumb Bar | AC009-01 | 1 | 66 | Handle Nut | AC003-02 | 1 |
| 22 | Thumb Bar Screw | BC050-01 | 2 | 67 | Line Memo Spring | AC022-01 | 1 |
| 23 | Gear Side Cover Screw "B" | BC057-01 | 3 | 68 | Line Memo Dial | AC162-01 | 1 |
| 24 | Spring Collar | AC088-01 | 1 | 69 | Handle Nut Cap | AC034-01 | 1 |
| 25 | Release Slider Spring | BC104-01 | 1 | 70 | Handle Nut Cap Screw | BC065-02 | 1 |
| 26 | Release Slider | BC039-01 | 1 | | | | |
| | | | | | | | |