
QUANTUM

TRX10F



Quantum TRX10F Spinning Reel Part List							
Key #	Description	Part No.	Qty.	Key #	Description	Part No.	Qty.
1	DRAG KNOB ASSEMBLY	AU332-01	1	31	CLUTCH ASSEMBLY	AU063-01	1
2	DRAG RETAINER	AU038-01	1	32	PINION GEAR	AU011-01	1
3	DRAG "D" WASHER	AU080-01	2	33	HANDLE SCREW CAP ASSEMBLY	DQ249-01	1
4	DRAG FRICTION WASHER	AU030-01	3	34	BODY	N/A	1
5	DRAG KEY WASHER	AU081-01	1	35	O/S GEAR BEARING	N/A	1
1	SPOOL ASSEMBLY	HAB321-01	1	36	O/S GEAR	AU053-01	1
7	SPOOL FRICTION WASHER	TG039-01	1	37	O/S SLIDER	AU025-01	1
8	CLICK GEAR	AU037-01	1	38	MAIN SHAFT SCREW	TG100-01	1
9	ROTOR NUT	AU006-01	1	39	SLIDER GUIDE	TG078-01	1
10	ROTOR NUT WASHER	N/A	1	40	SLIDER GUIDE SCREW	TG094-01	1
11	BAIL PIVOT SCREW	TG164-01	1	41	BODY BALL BEARING	CH027-01	1
12	ROTOR	N/A	1	42	DRIVE GEAR	N/A	1
13	KICK LEVER	AU019-01	1	43	BODY COVER BALL BEARING	CH027-01	1
14	BAIL SPRING SHAFT	BU115-01	1	44	BODY COVER ASSEMBLY	N/A	1
15	BAIL SPRING	BU117-01	1	45	BODY COVER SCREW "A"	TG057-01	2
16	ARM LEVER COVER	AU046-01	1	46	BODY COVER SCREW "B"	CU085-01	1
17	ARM LEVER COVER SCREW	BU085-01	1	47	ANTI-REVERSE CAM	WU090-01	1
18	LINE ROLLER SCREW	BU108-01	1	48	ANTI-REVERSE CAM SPRING	VG216-01	1
19	ARM LEVER	AU007-01	1	49	ANTI-REVERSE SPRING	DQ216-01	1
20	BAIL PIVOT SCREW	TG164-01	1	50	ANTI-REVERSE SWITCH	N/A	1
21	LINE ROLLER BEARING / BUSHING	VU158-01	1	51	ANTI-REVERSE SWITCH SCREW	N/A	1
22	LINE ROLLER	AU004-01	1	52	BODY REAR COVER	HAB250-01	1
23	LINE ROLLER BEARING	CT157-01	1	53	BODY REAR COVER SCREW	CU168-01	1
24	BAIL ASSEMBLY	AU347-01	1	54	HANDLE ASSEMBLY	HAB318-01	1
25	MAIN SHAFT	AU015-01	1	55	SPOOL ASSEMBLY	HAB321-01	1
26	CLUTCH RETAINER SCREW	UG094-01	3	56	BODY COVER SCREW "C"	N/A	1
27	CLUTCH RETAINER	DQ060-01	1	57	ROTOR NUT LOCK SCREW	N/A	1
28	PINION BEARING	DQ028-01	1	58	BAIL SPRING SHAFT HOLDER	N/A	1
29	PINION BEARING ADAPTER	AU190-01	1	59	LINE ROLLER FRICTION WASHER	DQ102-01	1
30	CLUTCH SLEEVE	TG139-01	1	60	LINE ROLLER WASHER	BU102-01	1

ReelSchematic