
QUANTUM

TRX20F



Quantum TRX20F Spinning Reel Part List

Key #	Description	Part No.	Qty.	Key #	Description	Part No.	Qty.
1	DRAG KNOB ASSEMBLY	BU332-01	1	32	PINION GEAR	BU011-01	1
2	DRAG RETAINER	TG038-01	1	33	HANDLE SCREW CAP ASSEMBLY	DQ249-01	1
3	DRAG "D" WASHER	TG080-01	2	34	BODY	BU001-01	1
4	DRAG FRICTION WASHER	TG030-01	3	35	O/S GEAR BEARING	UG157-01	1
5	DRAG KEY WASHER	TG081-01	1	36	O/S GEAR	UG053-01	1
7	SPOOL FRICTION WASHER	JG039-01	1	37	O/S SLIDER	UG025-01	1
8	CLICK GEAR	BU037-01	1	38	MAIN SHAFT SCREW	TG100-01	1
9	ROTOR NUT	TG006-01	1	39	SLIDER GUIDE	UG078-01	1
10	ROTOR NUT WASHER	N/A	1	40	SLIDER GUIDE SCREW	TG094-01	1
11	BAIL PIVOT SCREW	TG164-01	1	41	BODY BALL BEARING	CH027-01	1
12	ROTOR	BU009-01	1	42	DRIVE GEAR	BU012-01	1
13	KICK LEVER	BU019-01	1	43	BODY COVER BALL BEARING	AAA028-01	1
14	BAIL SPRING SHAFT	BU115-01	1	44	BODY COVER ASSEMBLY	BU023-01	1
15	BAIL SPRING	BU117-01	1	45	BODY COVER SCREW "A"	TG057-01	2
16	ARM LEVER COVER	BU046-01	1	46	BODY COVER SCREW "B"	CU085-01	1
17	ARM LEVER COVER SCREW	BU085-01	1	47	ANTI-REVERSE CAM	CU090-01	1
18	LINE ROLLER SCREW	BU108-01	1	48	ANTI-REVERSE CAM SPRING	VG216-01	1
19	ARM LEVER	BU007-01	1	49	ANTI-REVERSE SPRING	BU089-01	1
20	BAIL PIVOT SCREW	TG164-01	1	50	ANTI-REVERSE SWITCH	BU089-01	1
21	LINE ROLLER BEARING / BUSHING	CT157-01	1	51	ANTI-REVERSE SWITCH SCREW	TG135-01	1
22	LINE ROLLER	BU004-01	1	52	BODY REAR COVER	BU250-01	1
23	LINE ROLLER BEARING	CT157-01	1	53	BODY REAR COVER SCREW	CU168-01	1
24	BAIL ASSEMBLY	BU347-01	1	54	HANDLE ASSEMBLY	JAB318-01	1
25	MAIN SHAFT	BU015-01	1	55	SPOOL ASSEMBLY	JAB321-01	1
26	CLUTCH RETAINER SCREW	UG094-01	3	56	BODY COVER SCREW "C"	VG057-01	1
27	CLUTCH RETAINER	TG060-01	1	57	ROTOR NUT LOCK SCREW	TG094-01	1
28	PINION BEARING	AAA028-01	1	58	BAIL SPRING SHAFT HOLDER	BU116-01	1
29	PINION BEARING ADAPTER	BU190-01	1	59	LINE ROLLER FRICTION WASHER	DQ102-01	1
30	CLUTCH SLEEVE	AU139-01	1	60	LINE ROLLER WASHER	BU102-01	1
31	CLUTCH ASSEMBLY	TG063-01	1				

ReelSchematic