www.reelschematic.com

# SHIMANO®

## CURADO®

# CU-201B5




| Part No. | Description | Part No. | Description | Part No. | Description |
|---|---|---|---|---|---|
| BNT0015 | Drag Spring Washer | BNT1344 | “C” Lock | BNT1520 | Clutch Cam Retainer |
| BNT0031 | Ball Bearing | 13BNT56 | Brake Case Retainer Screw | BNT1521 | Clutch Cam |
| BNT0032 | Bearing Retainer | 1357BNT | Brake Case | BNT1522 | Clutch Pawl |
| BNT0042 | Line Guide Pawl | BNT1362 | Turnkey Pawl | BNT1523 | Clutch Pawl Spring |
| BNT0194 | Ball Bearing | BNT1467 | Level Wind Guard | BNT1525 | One-Piece Frame |
| BNT0425 | “E” Lock | BNT1469 | Line Guide | BNT1526 | Quick-Fire II Clutch Bar |
| BNT0664 | Spacer (B) | BNT1486 | Star Drag | BNT1527 | Right Side Plate |
| BNT0786 | Side Plate Screw (short) | BNT1490 | Anti-Reverse Ratchet | BNT1534 | Drive Gear |
| BNT0795 | Handle Nut Plate Screw | BNT1492 | Idle Gear (A) | BNT1535 | Pinion Gear |
| BNT0802 | Spool Tension Spacer (B) | BNT1493 | Drive Gear Washer | BNT1670 | Worm Bushing |
| BNT0803 | Spool Tension Spacer (A) | BNT1494 | Drive Shaft Washer (B) | BNT1671 | Worm Shaft Washer (B) |
| BNT0817 | Clutch Bar Screw | BNT1495 | Drive Shaft Washer (A) | BNT1672 | “E” Lock |
| BNT0830 | Spacer (optional) | BNT1497 | Drive Shaft Cover Screw | BNT1715 | Brake Collar (red) |
| BNT0987 | Multi Purpose Screw | BNT1499 | Clutch Plate Screw | BNT1788 | Handle Nut |
| BNT1092 | Pawl Cap | BNT1502 | Spacer (optional) | BNT1993 | Handle Nut Plate Assembly |
| BNT1106 | Star Drag Spring | BNT1506 | Line Guard | BNT1994 | Handle Assembly |
| BNT1133 | Yoke / Turnkey Pawl Spring | BNT1507 | Spool Assembly | BNT1995 | Cast Control Cap |
| BNT1206 | Roller Clutch Inner Tube | BNT1510 | Turnkey Dial | BNT1996 | Spool Tension Spring |
| BNT1207 | Roller Clutch Bearing | BNT1512 | Star Drag Nut | BNT1998 | Side Plate Screw (long) |
| BNT1211 | Key Washer | BNT1515 | Drive Shaft | BNT1999 | Idle Gear (C) |
| BNT1212 | Drag Washer (C) | BNT1516 | Drive Shaft Cover | BNT2000 | Worm Shaft |
| BNT1214 | Drag Washer (A) | BNT1517 | Clutch Plate | BNT2001 | Left Side Plate |
| BNT1289 | Star Drag Spacer | BNT1519 | Yoke | BNT2045 | Thumb Rest |

(090730)