SHIMANO

SLX A-RB

# SLXDC150HG



(51RL211150X)

Please note that the number of adjusting washersmay not be the same as shown in the exploded views. (Adjustment will vary with each individual product.)

The (2396) Roller clutchcannot be replaced by the customer.
To replace these parts, please request after-sales service.

| Part No. | Description | Part No. | Description | Part No. | Description |
|---|---|---|---|---|---|
| BNT0031 | Ball Bearing | BNT5376 | Drag Spring Washer | BNT5945 | Clutch Cam Retainer |
| BNT0686 | E Lock | BNT5380 | Drag Washer | BNT5946 | Clutch Cam |
| BNT1672 | E Lock | BNT5383 | Line Guide Pawl | BNT5948 | Screw |
| BNT1696 | Cast Control Spacer | BNT5386 | Ball Bearing | BNT5949 | Clutch Guard Assembly |
| BNT2127 | Star Drag Spacer | BNT5503 | O Ring | BNT5951 | Screw |
| BNT2224 | Spool Tension Spacer | BNT5609 | Screw | BNT5952 | Screw |
| BNT2396 | Roller Clutch Bearing | BNT5640 | Screw | BNT5969 | Bearing Seal |
| BNT3208 | Star Drag Click Plate | BNT5641 | Handle Nut Plate | BNT6052 | Washer |
| BNT4124 | Star Drag Spring | BNT5654 | Idle Gear | BNT6159 | Handle Nut |
| BNT4130 | Drag Washer | BNT5659 | Idle Gear | BNT6357 | Brake Dial |
| BNT4343 | Ball Bearing | BNT5661 | Level Wind Guard | BNT6358 | Line Guide Assembly |
| BNT4729 | O Ring | BNT5689 | Worm Shaft | BNT6359 | Spool Assembly |
| BNT4863 | Star Drag Nut | BNT5713 | Handle Knob Seal | BNT6362 | Left Side Plate |
| BNT4868 | Key Washer | BNT5714 | Screw | BNT6363 | Frame |
| BNT4874 | Pawl Cap | BNT5723 | Washer | BNT6364 | Level Wind Protector |
| BNT4886 | Clutch Pawl Assembly | BNT5729 | Washer | BNT6365 | Clutch Button |
| BNT4922 | Drive Gear | BNT5731 | Spacer | BNT6366 | Clutch Bar Guide B |
| BNT4932 | Click Spring | BNT5742 | Washer | BNT6367 | Clutch Bar Guide A |
| BNT5264 | Anti-Reverse Ratchet | BNT5779 | Screw | BNT6370 | Screw |
| BNT5286 | Pinion Gear | BNT5901 | Left Side Plate Substrate | BNT6371 | Click Ring |
| BNT5308 | Washer | BNT5902 | Screw | BNT6372 | Left Side Plate Cam Lever |
| BNT5310 | Idle Gear Pin | BNT5903 | Washer | BNT6373 | Cam Lever Retainer |
| BNT5316 | Click Pin | BNT5904 | Bearing Retainer | BNT6374 | Stabilizer Bar |
| BNT5319 | Bearing Retainer | BNT5905 | Spool Shaft Spacer | BNT6375 | Clutch Plate |
| BNT5320 | O Ring | BNT5906 | Screw | BNT6376 | Cast Control Cap |
| BNT5327 | Idle Gear Spring | BNT5932 | Screw | BNT6378 | Right Side Plate Assembly |
| BNT5329 | Drive Shaft Retainer | BNT5933 | Roller Clutch Inner Tube | BNT6379 | Handle Assembly |
| BNT5334 | Bushing | BNT5934 | Drive Shaft | BNT6814 | Left Side Plate Assembly |
| BNT5337 | Clutch Pawl Spring | BNT5942 | Yoke Spring | | |
| BNT5346 | Spacer B | BNT5943 | Yoke | | |
| BNT5375 | Star Drag | BNT5944 | Screw | BNT4692 | B-100 Oil (Accessory) |