



STRADIC 4000 95

ST4000FD

Part #	Description	Part #	Description	Part #	Description
RD 0026	Ball Bearing	RD 3402	Cover Screw	RD 3516	Anti-Reverse Cam Spring
RD 0041	Drive Gear Washer	RD 3406	Handle Screw Cap Assembly	RD 3517	Anti-Reverse Cam
RD 0071	Rotor Nut	RD 3423	Side Cover Screws	RD 3518	Anti-Reverse Pawl Screw
RD 0540	Bail Trip Lever Screw	RD 3474	"O" Ring	RD 3519	Anti-Reverse Pawl
RD 0787	Nut Lock Screw	RD 3486	Oscillating Pawl	RD 3520	Anti-Reverse Pawl Spring
RD 0930	Ball Bearing	RD 3490	Anti-Reverse Lever Assembly	RD 3521	Anti-Reverse Pawl Spacer
RD 1509	Bail Spring	RD 3501	Drag Knob	RD 3522	Worm Bearing
RD 1511	Lever Spring	RD 3503	Spool Washer	RD 3523	Idle Gear
RD 1891	Multi Purpose Screw	RD 3504	Rotor	RD 3524	Worm Shaft
RD 2298	Spacer	RD 3505	Bail Assembly	RD 3525	Drive Gear
RD 2309	Slider Retainer Screw	RD 3506	Bail Spring Guide (A)	RD 3527	Oscillating Slider Bushing
RD 2362	Spool Support	RD 3507	Bail Spring Guide (B)	RD 3529	Oscillating Guide Holder
RD 2401	Ball Bearing	RD 3508	Bail Spring Cover	RD 3530	Oscillating Guide
RD 2409	Worm Shaft Spacer	RD 3509	Bail Trip Lever	RD 3531	Rear Protector
RD 2867	Bushing	RD 3510	Counterbalance Cover	RD 3533	Handle Assembly
RD 2904	Spool Assembly	RD 3511	Anti-Reverse Lock Out	RD 3936	Oscillating Pawl Cover Screw
RD 3088	Bail Spring Cover Screw	RD 3512	Anti-Reverse Lock Out Spring	RD 4057	Main Shaft
RD 3304	Bearing Spacer	RD 3513	Lock Out Spring Holder	RD 4058	Oscillating Pawl Cover
RD 3305	SIC Ceramic Roller	RD 3514	Bearing Retainer	RD 4059	Oscillating Slider
RD 3307	Line Roller Bushing	RD 3515	Pinion Gear	RD 4137	Body Assembly