Care and Maintenace

LAKETROLLER

INSTRUCTIONS

Your Scotty laketroller is constructed of corrosion resistant materials. The following regular maintenance checks should be performed:

- 1. Rinse with fresh water after every use.
- 2. Rountinely check the stainless steel fastenings with a screwdriver to see that they are snug and secure.
- Do not use any lubricants. Lubricants will attack the plastic components.
- 4. Do not expose the downrigger to ultraviolet light for extended periods of time.


To obtain parts, information or to locate the warranty service center nearest you contact:

Scotty Fishing and Marine Products

2065 Henry Ave West Sidney, BC Canada V8L 5Z6

Tel: (250) 656-8102 Fax: (250) 656-8126 Toll Free: 1800-214-0141 Email: scotty@scotty.com

www.scotty.com





The Way To Fish™

Mounting

Bracket Mount Laketroller

The bracket mount laketroller is designed to enter the mounting bracket only when pointing inboard. And is locked in every other direction.

To ensure the mounting bracket is correctly positioned, the 'Scotty" trademark on the bracket should read right way up, when looking from inboard.




When mounting the bracket, a wood or metal backing plate on the underside of the gunnel should be used to distribute the load.


When side mounting, the bracket should be mounted as flush to the gunnel top as possible to allow full swivel rotation.

Clamp Mount Laketroller

If necessary, use a small block of wood for spacing on the outside of the gunwale. Make sure your laketroller is securely clamped. A safety line tied from the laketroller to the boat is a good idea.



How to use your Laketroller



"Mini Power grip " release instructions

- 1. Attach the snap swivel of the Mini Power Grip release to the downrigger weight.
- Attach your fishing line to the Mini Power Grip release by squeezing the jaws apart and placing your fishing line between the pads. The release tension is lighter at the outer tip, and is heavier the further into the jaws you place the line.
- 3. The "tension adjuster" can be moved forward or back to double the release tension.

